

[HTTPS://WWW.NATURE4.ORG/](https://www.nature4.org/)



TREETALKER VERSION: TT+
Suggested firmware: TT3_2_plus.5_0h

TT+ User Manual



September 2020

Address:

Nature 4.0 SB Srl
via Fortunato Zeni, 8
38068 Rovereto (TN), ITALY
VAT IT02507200224


Contact info:

Micaela@nature4.org
+393456627611

TABLE OF CONTENTS

1.	Introduction.....	1
2.	TT+ Layout	2
3.	TT+ Data String.....	4
4.	Explanation of Data String.....	5
4.1.	Date & Time	5
4.2.	Serial Number	5
4.3.	Record Number.....	5
4.4.	Device Type.....	5
4.5.	Timestamp	5
4.6.	Ref & Heat Probes Temperature	6
4.6.1.	Sap flow.....	7
4.7.	Growth Rate.....	7
4.8.	Battery Voltage.....	9
4.9.	Data Resolution.....	10
4.10.	Meteorological Data.....	10
4.11.	Tree Stability	10
4.12.	Stem water Content (StWC %)	10
4.13.	Spectral Band.....	11
5.	TT+ Installation.....	12
6.	Acknowledgment.....	15
7.	References.....	15
8.	Appendix.....	16
8.1.	Variation of sap flux density against air temperature and xylem moisture content in Platanus species	16
8.2.	Transmitted radiance below the canopy in Malus Domestica species	16
8.3.	Technical characteristics of TT+.....	17
8.4.	LIST OF TT+ COMMANDS (only by direct serial connection)	17

1. Introduction



Nature4.0 is developing a set of IoT devices dedicated to environmental monitoring including terrestrial ecosystems and ocean applications. One of our application (see www.nature4.org) is the TreeTalker which we provide in several versions: TT+ (using thermal dissipation for sap flow), TT++ (using heat pulse velocity), TT-CARBON (for specific carbon sequestration studies) and TT-FIRE (for fire prevention and detection).

The present manual refers to TT+ that use the thermal dissipation probe for sap flow measurements (Granier method).

A brief on sap flow measurements by the thermal dissipation method (Granier method)

The transpiration rate of whole plants is closely approximated by the sap flow rate in the main stem or trunk. For these reasons there is a need for a relatively simple and affordable device to continuously monitor the sap flow rate in trees of all sizes. A method for that purpose was proposed by Granier (Granier, 1987), who inserted a needle, containing an electric heater, in the sapwood of a trunk and measured the difference between the temperature of the heated needle and that of the sapwood some distance below the needle. The method is relatively simple and it is called the Thermal Dissipation Probe (TDP) method. TDP heated needle is an improved heat dissipation sensor, as proposed by Granier, which measures the temperature of a line heat source implanted in the sapwood of a tree, referenced to the sapwood temperature at a location well below the heated needle. The probe measures the sapwood heat dissipation, which increases with sap flow and cool the heat source. When the sap flow velocity is zero or minimal, the temperature difference (ΔT) between the two sensors is maximal. When the flow increases, this temperature difference decreases. Moreover, many factors are involved to decide about the number of inserted probes in the trunk to measure sap flow, such as tree's diameter and stem uniformity. A single probe may be used on trees 3-5" (to 125 mm) in diameter, but two or more probes are recommended for trees in the 5-8" (to 200 mm) diameter range. Very large trees, over 8" (200 mm) may require four or more. In closed canopies, where trees are more uniform in size and spacing, good results are reported with just one probe per tree, regardless of size. It should be understood that the sap flow velocity varies within the sapwood, so unknown parameters like sapwood thickness introduces some uncertainty in the calculation of the sap flow.




Figure 1. Sap flux density in greenwood stem based on Granier method

In the following, Nature 4.0 describes a new product, TT+, which meets the above needs to measure sap flow and some other variables related to tree physiology and meteorological parameters.

2. TT+ Layout

Taking advantage of IoT, a new device the Tree-Talker version “TT+”, is developed to measure simultaneously important individual tree scale ecophysiological parameters as well as some additional ecosystem-related variables. Key parameters are:

- 1) Tree radial growth, as an indicator of photosynthetic carbon allocation in biomass
- 2) Sap flow, as an indicator of tree transpiration and functionality of xylem transport
- 3) Xylem moisture content as indicator of hydraulic functionality
- 4) Light penetration in the canopy in terms of fractional absorbed radiation
- 5) Light spectral components related to foliage dieback and physiology
- 6) Tree stability parameters to allow real time forecast of potential tree fallings.

Additional parameters such as air relative humidity and air temperature will be also monitored at high frequency to have comparable time scale between abiotic parameters and short-term plant responses.







Figure 2. TT+ layout

TREETALKER VERSION: TT+

TT+ Structure	
1	Microprocessor reset button
2	Microprocessor External crystal 8 MHz
3	Microprocessor
4	Square frequency generator
5	Voltage regulator 3,3V
6	Accelerometer
7	Microprocessor serial programming header
8	Radio Antenna 868MHz
9	Diode, save device from reverse battery polarity insertion
10	Radio Module 868MHz
11	Heat probe connector
12	Reference probe connector
13	Growth sensor connector
14	Battery connection
15	Spectrometer




Figure 3. TT+ structure




Figure 4. Heater and reference probes in Granier_Type method

3. TT+DataString

Each TreeTalkers is hosted by a TTcloud and then all data transmits to the data server at the following address www.altervista.org.

For each forest site, one TTcloud with a cluster of TreeTalkers is connected. A cluster maximum can include 48 TTs but, to avoid radio collisions, the ideal situation is to keep 20 to 30.

You can access your data in the following commands:

<http://naturetalkers.altervista.org/'insert your TTcloud ID'/ttcloud.txt>

Click the link below to see an example of TT+ data string:

<http://naturetalkers.altervista.org/C1960060/ttcloud.txt>

10.02.20 13:14:46,52010001;263;4D;1581336000;35316;35135;62750;42514;17;26;210;-3894;0;-76;0;-1319;0;35234;29259;8905;79185

10.02.20

13:15:02,52010001;264;49;1581336000;3315;2985;10053;12202;12064;12370;7513;9705;11017;9242;6211;4368;50;3

In order to organize the data, each string of TT+ can be arranged with specific headers as a below table format.

Table 1. TT+ data sample

TT+ 3.2. (Granier_Type+12 Spectral Bands)			
<i>string' type 4D</i>	<i>example</i>	<i>string' type 49</i>	<i>example</i>
Server Date	10.02.20	Server Date	10.02.20
Server Time	13:14:46	Server Time	13:15:02
TT ID	52010001	TT ID	52010001
record_number	263	record_number	264
device type	4D	device type	49
Timestamp	1581336000	Timestamp	1581336000
Tref_0 [d.n.]	35316	AS7263_610 [d.n.]	334
Theat_0 [d.n.]	35135	AS7263_680 [d.n.]	70
growth sensor [d.n.]	56434	AS7263_730 [d.n.]	53
adc_bandgap [d.n.]	42514	AS7263_760 [d.n.]	48
number of bits	17	AS7263_810 [d.n.]	56
Air relative humidity [%]	26	AS7263_860 [d.n.]	51
Air temperature [10*° C]	210	AS7262_450 [d.n.]	50
g_z(mean) [d.n.]	376	AS7262_500 [d.n.]	67
g_z(std.dev) [d.n.]	0	AS7262_550 [d.n.]	297
g_y (mean) [d.n.]	1980	AS7262_570 [d.n.]	243
g_y (std.dev) [d.n.]	0	AS7262_600 [d.n.]	362
g_x (mean) [d.n.]	3604	AS7262_650 [d.n.]	145
g_x (std.dev) [d.n.]	0	integration time	50
Tref_1 [d.n.]	35234	gain	3
Theat_1 [d.n.]	29259		
StWC [freq (Hz)]	49951		
adc_Vbat [d.n.]	79185		

Note:

The second way to reach the data is connecting directly to a device. Each TT+ has 16 Mb internal memory in order to save data (> than 10 years). Data can be uploaded directly from TT+ by 6 pins cable which can connect to microprocessor serial programming header (see figure 3 block no. 7).




Figure 5. Uploading TT+ data directly by 6 pins cable

4. Explanation of DataString

4.1. Date & Time

- “10.02.20 13:14:46”; is the timestamp of the server when the router transmits the data. This timestamp may or not coincide with the real timestamp of the measurement (see later) since it depends on the availability of the GPRS signal. Thus, it cannot be used as real timestamp.

4.2. Serial Number

- “52010001”; Serial number of TT+ which distinguish each device from others

4.3. Record Number

- “263”; progressive number of the record in memory (hexadecimal) (in order to convert to the number, use the following formula in EXCEL:

$$\text{Equation 1.} \quad f = \text{HEX2DEC}*(\text{record_number})$$

4.4. Device Type

- “4D” & “49”; identification code for the device type. 4D and 49 codes are scheduled for the different measurement logs in TT+.

4.5. Timestamp

- “1581336000”; timestamp of the router when the individual device send the data string. The timestamp is the number of seconds since 1st January 1970. This way of representing time is

called UNIX timestamp or EPOCH time and it is the basis of any computer in the world (<https://www.epochconverter.com/>).

- Timestamp have to convert in real time by the following formula:

$$\text{Equation 2.} \quad f = (((\text{Timestamp}/60)/60)/24) + \text{DATE (1970, 1, 1)}$$

For example, 1581336000 timestamp is equal to 02/06/2020 11.00 AM

4.6. Ref & Heat Probes Temperature

Reference probe (Tref [d.n.]) and heating probe (Theat [d.n.]) transmit stem temperature data in forms of digital number before and after heating. In order to convert the digital numbers to temperature data, please apply the below polynomial regression equation:

$$\text{Equation 3.} \quad \text{Temperature (}^{\circ}\text{C)} = 127.6 - 0.006045 * \text{D.N.} + 1.26\text{E-}07 * \text{D.N.}^2 - 1.15\text{E-}12 * \text{D.N.}^3$$

$$S = 0.999273$$

$$R\text{-Sq} = 99.9\%$$

$$R\text{-Sq(adj)} = 99.9\%$$




Figure 6. Relation between digital number & temperature with polynomial fitting curve

Table 2 shows an example of converting the digital numbers to temperature data.

Table 2. Example of converted digital numbers to temperature ($^{\circ}\text{C}$)

<i>Condition</i>	<i>probe</i>	<i>D.N.</i>	<i>Temperature ($^{\circ}\text{C}$)</i>
<i>Before heating</i>	Tref_0 [d.n.]	35316	20.62
	Theat_0 [d.n.]	35135	20.88
<i>After heating</i>	Tref_1 [d.n.]	35234	20.74
	Theat_1 [d.n.]	29259	29.79

4.6.1. Sap flow

After recording temperature data before and after heating inside stem, we are able to estimate sap flow which in this case the method follows Granier_Type approach. The TT+ version is designed to measure sap flow according to the thermal dissipation method (TDP) with cyclic heating system (10 minutes of heating/ 50 minutes of cooling). A probe pairs is inserted in the main trunk with a vertical separation of 10 cm, facing north to avoid direct solar heating. One of the probe is heated while the other is used to measure the reference temperature and includes a capacitive sensor of wood humidity. Granier equation is used to determine sap flux density in TDP devices.

$$\text{Equation 4.} \quad F_d = 118.99 \left[\frac{\Delta T_{max} - \Delta T}{\Delta T} \right]^{1.231}$$

Where F_d is the sap flux density ($\text{gm}^{-2}\text{s}^{-1}$), ΔT is the actual temperature gradient between the two probes after heating and ΔT_{max} the maximum temperature gradient measured between the probes after heating in a given time period.

Please check the below link for the reference paper:

<http://citeseerx.ist.psu.edu/viewdoc/download?doi=10.1.1.600.943&rep=rep1&type=pdf>

In addition, you can apply Do & Rocheteau method to estimate sap flux density to consider both temperature measurements at the end of cooling (T_{ref_0} & T_{heat_0}) and heating (T_{ref_1} & T_{heat_1}) periods.

$$\text{Equation 5.} \quad F_d = 118.99 \left[\frac{\Delta T_{max}}{\Delta T_{on} - \Delta T_{off}} - 1 \right]^{1.231}$$

$$\Delta T_{on} = T_{heat_1} - T_{ref_1} \quad \text{and} \quad \Delta T_{off} = T_{heat_0} - T_{ref_0}$$

Please check the below link for the reference paper:

<https://academic.oup.com/treephys/article/22/9/649/1655537>

4.7. Growth Rate

- 62750; stem radial growth is measured by an infra-red pulsed distance sensor positioned at few centimeters away from the tree trunk's surface and kept in place by a carbon fiber stick anchored in the xylem. The mentioned digital number shows an example of sharp sensor record – when it is 0 in this case the sensor is not installed.




Figure 7. Installed growth sensor which can measure distance between bark to sensor

Considering the total length of sharp sensor (50 mm) and the insertion depth of the sensor in a tree (typically between 10 to 18 mm), below are some recalculations of source data to find a calibration regression model to convert recorded digital number by growth sensor to valuable length unit.




Figure 8. Data source of recorded digital numbers by sharp sensor equivalent to the different-distance set

A 2nd-degree polynomial regression model applied to analyze the relationship between distance and reported digital numbers by a sharp sensor.

Equation 6. $\text{Distance (mm)} = 0.000000008 * (\text{sharp sensor D.N.})^2 - 0.0016 * (\text{sharp sensor D.N.}) + 89.032$

$$R^2 = 0.9947$$

Table 3. Example of data sample

<i>sharp (D.N.)</i>	<i>distance (mm)</i>
40000	37.832
45000	33.232
60000	21.832
70000	16.232
85000	10.832

The equation is applicable for the range of 40000 to 85000 sharp sensor D.N. which is equal to 38 to 10 mm, correspondingly. Please see the below graphs.




Figure 9. Data selection to define relationship between sharp sensor reported-values and corresponding distances

4.8. Battery Voltage

To have the battery voltage in mV (millivolt), apply the formula 9:

$$\text{Equation 7.} \quad \text{Battery_Voltage (mV)} = 2 * \text{mV_bandgap} * \frac{\text{adc_Vbat [d.n.]}}{\text{adc_bandgap [d.n.]}}$$

Where, mV_bandgap is the band gap reference voltage of the Atmel328 (=1100 mV per datasheet), adc_Vbat [d.n.] and adc_bandgap [d.n.] are ADC converter numeric values. Table 3 shows an example of estimated supply voltage.

Table 4. Example of estimated supply voltage (mV) based on adc_Vbat [d.n.] and adc_bandgap [d.n.]

Variable	digital number	Battery voltage (mV)
mV_bandgap (constant)	1100	4097.64
adc_bandgap [d.n.]	42514	
adc_Vbat [d.n.]	79185	

Note:

Even if the microprocessor and other components will run under low battery (in principle at 2.2 V) we do suggest to recharge battery at the level of 3.5V, below such threshold we cannot guarantee on the proper functioning of the sensors.

4.9. Data Resolution

- “17”; number of measurement resolution bits

4.10. Meteorological Data

- “26”; air relative humidity (%)
- “210”; air temperature ($\times 10$, ° C then 21 ° C)

Air temperature and humidity sensor is placed facing a small hole in the back of the box covered by a Goretex™ membrane to avoid water to go inside but still permeable to water vapor.

4.11. Tree Stability

- “-3894”; value of the acceleration on the Z axis (Note: 4096 corresponds to 1g)
- “0”; square of the Z variance on the measure (standard deviation)
- “-76”; value of the acceleration on the Y axis
- “0”; square of the Y variance on the measure
- “-1319”; value of the acceleration on the X axis.
- “0”; square of the X variance on the measure.

Treetalker is able to record oscillation of tree due to gravity with Spherical Coordinate System. With basic trigonometry, ϕ , the angle between the gravity vector and the z-axis can be assessed by using equation 10 (Fisher, 2010). This capability will improve the monitoring of forest ecosystem resilience against wind impact.

$$\text{Equation 8.} \quad \phi = \tan^{-1} \left(\sqrt{A_{X,OUT}^2 + A_{Y,OUT}^2} / A_{Z,OUT} \right)$$

4.12. Stem water Content (StWC %)

“8905” frequency domain measurement (ECf (Hz)).

Stem humidity measurement is alternative capability of TT+ which is expressed as frequency signal with the range of 7000 to 14000 Hz in green wood. The range of frequencies is significantly influenced by environmental factors. High frequency occurs in very hot days and shows less stem water content. Considering the effect of wood density on frequency data, calibration models are performed on 2 different harvested stem samples (*Fagus sylvatica* L. & *Pinus sylvestris* L.) to convert the sensor-reported values to stem volumetric water content. Calibration formulas for other species are still under investigation.

In order to estimate the amount of stem water content, follow the steps below:

Step 1: Applying temperature sensitivity equation and converting ECf to ECf_{Tref}:

$$\text{Equation 9.} \quad ECf_{Tref}(Hz) = ECf(Hz) - 7.3 \times (NTCI(^{\circ}C) - NTCI_{ref}(^{\circ}C))$$

$$NTCI_{ref} = 29^{\circ}C$$

Step 2: Estimating stem water content (StWC %) based on linear calibration model for different species type.

$$\text{Equation 10.} \quad \text{StWC (\%)} = m \times \text{EcT}_{\text{ref}} \text{ (Hz)} + b$$

Table 5. Coefficients 'm' and 'b' are presented for a linear equation in the standard form in different species

Calibration equation	m	b	R ²
<i>Fagus sylvatica</i> L.	-0.0034	54.897	0.979
<i>Pinus sylvestris</i> L./ $\text{EcT}_{\text{ref}} < 14500 \text{ Hz}$	-0.0008	30.023	0.969
<i>Pinus sylvestris</i> L./ $\text{EcT}_{\text{ref}} > 14500 \text{ Hz}$	-0.01	173.53	0.978




Figure 10. Linear calibration curves for wood samples of *Fagus sylvatica* L. and *Pinus sylvestris* L.

Note: To skip the wound impact on reference probe after installation of TT+, we suggest to ignore the first week of ECf (Hz) data

4.13. Spectral Band

In second line of strings with 49 device type, first 4 data are same as type 4D. The rest shows canopy light transmission in 12 spectral bands 610+, , 680+, 730+, 760+, 810+, 860+ nm, 450*, 500*, 550*, 570*, 600*, 650* (* $\pm 20 \text{ nm} + \pm 10 \text{ nm}$). The internal spectrometer has been re-calibrated with a professional lab spectrometer in order to take into account the geometry of the system, including the glass shield.

The below table shows calibrated equations to convert the digital numbers (DN) in corrected spectral band:

Table 6. Calibration formulas for each wavelength in spectral bands data

<i>Spectral Bands</i>	<i>Band (wavelength peak, nm)</i>	<i>Calibration Formula</i>
Near Infrared	AS7263_610 [d.n.]	# -312.45+(1.6699*DN)
	AS7263_680 [d.n.]	# -561.56+(1.5199*DN)
	AS7263_730 [d.n.]	# -1511.2+(1.6209*DN)
	AS7263_760 [d.n.]	# -1012.5+(1.4549*DN)
	AS7263_810 [d.n.]	# 91.58+(0.8414*DN)
	AS7263_860 [d.n.]	# 334.88+(0.531*DN)
Visible Light Spectrum	AS7262_450 [d.n.]	# -212.62+(0.4562*DN)
	AS7262_500 [d.n.]	# -232.13+(0.6257 *DN)
	AS7262_550 [d.n.]	# -842.1+(1.0546 *DN)
	AS7262_570 [d.n.]	# -666.72+(1.0462 *DN)
	AS7262_600 [d.n.]	# -328.08+(0.8654 *DN)
	AS7262_650 [d.n.]	# 202.77+(0.7829*DN)

- 50; is the integration time of spectrometer (it is multiplied x2.8 ms from hardware) default= 50 equivalent to 140 ms
- 3; is the gain. Can be set between 0 and 3 (0=1, 1=3.7x, 2=16x, 3=64x) default is 3.

5. TT+ Installation

In order to install TreeTalker, Please follow below steps:

Step 1. TT+, battery pack, belt and support plates should be prepared (figure 9).



Figure 11. TT+, battery pack, belt and support plates

TREETALKER VERSION: TT+

Step 2. Prepare some basic instruments such as drill, compass, hammer, glue, probes and angle templates to start installation (see figure 10).



Figure 12. Additional instruments to do installation

Step 3. Mostly TT+ is installed in DBH (Diameter at breast height) and toward north side, while it's better to put battery pack toward south side to save more energy by solar panel (figure 11).



Figure 13. Setting direction of TT+ and battery

Step 4. Fix TT+ and battery pack by belt and support plated with fastening and drilling them to the trunk, respectively (figure 12).



Figure 14. Fixing TT+ and battery pack to the trunk

Step 5. Mounting TT+ to the trunk should be with 20 degree angle to decrease the effect of stem shade on spectral bands data (figure 13).



Figure 15. Setting TT+ with 20 degree angle than trunk

Step 6. Use drill bit with 2 mm size to make a hole for growth sensor, put some glue on the top of fiber rod and then 10 to 18 mm of the rod should be inserted in the hole (figure 14).



Figure 16. Drilling a hole for fiber rod and inserting growth sensor in the trunk

Step 7. Installing Granier type probes: In order to insert heater and reference probes to the trunk, first two template holes can be drilled by bit with 3 mm size with almost 10 cm distance, then heater probe can easily inserted in the upper hole due to being rounded shape, whereas, regards to reference probe form, lower round hole should change to square shape hole and finally ref probe can insert in the stem (figure 15). In order to make a square hole you need to create a tool (as in figure 15) or use a Dremel cutter model 9901 (3.2 mm).

https://www.dremel.com/en_US/products/-/show-product/tools/9901-tungsten-carbide-cutter.



Figure 17. Heater and reference probes template to drill holes

6. Acknowledgment

We acknowledge the technical support of Dromo Elettronica s.r.l (Italy) and we wish to thank Damiano Gianelle, Luca Belevi, Roberto Zampedri, Isaac Chini and Mauro Cavagna from Fondazione Edmund Mach for their help and support with Tree-Talkers installation and testing in the lab. A special thanks to Shahla Asgharinia for preparing the manual.

7. References

- Fisher, C.J., 2010. Using an accelerometer for inclination sensing. AN-1057, Appl. note, Analog Devices.
- Granier, A. (1987). Evaluation of transpiration in a Douglas fir stand by means of sap flow Measurements. *Tree Physiology*, 3:309-320.
- Valentini, R., Marchesini, L. B., Gianelle, D., Sala, G., Yarovslavtsev, A., Vasenev, V. I., Castaldi, S., (2019). New tree monitoring systems: from Industry 4.0 to Nature 4.0. *Annals of Silvicultural Research* 43(2) (in press)

8. Appendix

8.1. Variation of sap flux density against air temperature and xylem moisture content in *Platanus* species




Figure 18. Dynamics of xylem moisture content of main stem with sap flux and air temperature in hourly scale

8.2. Transmitted radiance below the canopy in *Malus Domestica* species




Figure 19. Average transmitted radiance below canopy at 11 am to 14 pm in 4 selected *Malus* trees

8.3. Technical characteristics of TT+

	Component	Description
TT (TreeTalker)	Sap flow	Reference and heated temperature probes (± 0.1 °C). Thermistors manufacturer: Murata Electronics. Model: NCU18XH103F6SRB
	Stem humidity	Capacitive sensor MicroPCB (20x3x2) mm with copper plates.
	Canopy light transmission	Radiometer-12 spectral bands (450, 500, 550, 570, 600, 610, 650, 680, 730, 760, 810, 860 nm) (± 10 nm or ± 20 nm). Manufacturer: AMS. Model: AS7262 (Visible range), AS7263 (Near Infra-Red range)
	Tree trunk radial growth	Infra-red distance sensor (± 100 μ m) Manufacturer: SHARP. Model: GP2Y0A51SK0F
	Tree trunk axis movement	Accelerometer ($\pm 0.01^\circ$) Manufacturer: NXP/Freescale. Model: Si7006
	Air temperature and humidity	Thermohygrometer (± 0.1 °C ; ± 2 %). Manufacturer: Silicon Labs. Model: MMA8451Q
	Flash memory for data storage	16Mbyte
	LoRa module for data transmission	Transmission 600 m (in urban/rural environment). It can reach >3 km in case line of sight
	4 Li-Ion batteries + solar panel	3.7 V

8.4. LIST OF TT+ COMMANDS (only by direct serial connection)

With connecting directly to the TT+ by 6 pins cable, the below list could be sent to the device in order to read, delete or change the data. To connect the device you can use the provided cable with an FTDI32 converter and USB port. Once you connect with a USB port in your PC you have to use a simple serial monitor software such as serial Arduino monitor or app like PuTTY (<https://putty.org/>) with baud rate = 38400, parity= N, data bits=8, stop bits=1.

List of commands:

SN=2XXXXXXXXX.

(changing serial number)

DEFAULT

(resetting parameters)

CLEAR

(Clear all data logs)

READ_ALL

(Read all data store in TT+ flash memory as emergency backup)

TESTMODE followed by END

(These commands put TT+ in test mode. All data are sequentially taken every 1 minute and displayed on monitor for testing/checking sensor or using in special research mode – please consider that you have about 10 seconds to send the string TESTMODE after TT+ initialization, after this time TT+ enter in sleep mode)

Note: Commands must be written in capital letters, no blanks